



# Internal Battery Circuit Connector

This guide will show you how to install the internal battery circuit connectors

Written By: Nick Oleskowicz



## INTRODUCTION

This guide will teach the reader to install a new Battery Circuit Connector into the battery case. This may need to be done if the batteries are not delivering electricity into the camera.

---



### TOOLS:

- [64 Bit Driver Kit](#) (1)
-




## Step 1 — Batteries




- Flip the camera over so the bottom is facing you.

## Step 2



- Open the cover on the bottom by sliding it in the direction of the arrow.

### Step 3



- Remove the batteries by pulling up on the top with your fingers.


### Step 4 — Internal Battery Circuit Connector



- Remove the three screws from the circuit connector.



## Step 5



- Remove the connector from the battery holder door.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-14 02:34:57 AM.